

Aquafil Bold 850BF

Installation Details

AQ-BO850BF

1. EXCAVATE

Excavate a footing 500mm deep by 400mm square.

2. LEVEL

Ensure cage is level.
If ground is not level, one edge must be flush with highest footing edge.

3. WATER

Install water supply through the water access hole and extend 100mm above ground level.

4. DRAINAGE

Connect 90mm Plumbqwik to stormwater drain system or soaker pit.

**Civiq recommends Everhard Series 450 Stormwater Pit. Refer to manufacturers instructions regarding site preparation and correct installation.*

5. CONCRETE

Pour 20mpa concrete into drainage cage. Slab should be a 100mm thick under the product for wheelchair users.

6. CURE

Allow concrete mix cure for 2 days before installing product.

7. INSTALL

Bolt the product to the 4 x M12 bolts. Do not remove the M12 nuts on the bottom of the drainage tray. These provide clearance for the water to drain.

8. CONNECT

Remove the back panel to access the internal plumbing. Connect the product to the water supply via a 15mm BSP flexible hose.

