


For freestanding mounting to concrete slab with sub-surface water and drainage feed

NOTE: To access the connections inside the unit, remove the bottom panel with the black suction tool supplied. See below for details.



For freestanding mounting to concrete slab close to a building wall with rear entry for water and drainage feed

NOTE: To access the connections inside the unit, remove the bottom panel with the black suction tool supplied. See below for details.

